

BRUSH INSTALLATION AND USE INSTRUCTIONS

IMPORTANT: READ INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO USE THE BRUSH.

The brush can be used with the Loctite Bond-A-Matic™ 2000 Dispensing System equipped with the Vari-Drop Applicator, the Loctite Model 27-A Pencil Applicator and the Loctite Model 20-A Advancing Head Applicator.

This brush can be used to apply low viscosity Loctite anaerobic adhesives and sealants up to 2000 cps viscosity, and Loctite accelerators and primers.

The brush can be installed on the Vari-Drop Applicator by firmly pushing it onto the tapered nozzle. A light film of silicone grease, Loctite part number 997569, should be applied to the nozzle so that the brush does not bond to the nozzle.

When the applicator is not being used, the brush should be removed from the nozzle and rinsed clean with Loctite Safety Solvent or 1,1,1-trichloroethane. This will prevent curing of the adhesive or sealant in the brush.

ORDERING INFORMATION:

Part Number	Description
998390	Brush (Box of 10)

The Loctite logo is rendered in a bold, black, sans-serif font. The letters are thick and closely spaced, with a slight shadow effect that gives it a three-dimensional appearance. The 'O's are particularly prominent due to their size and the way they connect to the 'L' and 'T's.

Rocky Hill, CT 06067

Loctite is a registered trademark and Bond-A-Matic and Vari-Drop are trademarks of Loctite Corporation, Rocky Hill, Connecticut 06067.

998391