

Subject: Loctite® Syringe Finger Switch (# [988896](#)) for use with Digital Syringe Dispenser (#[883976](#))

Current Issue: The Digital Syringe Dispenser (#883976) is activated by a footswitch that has a right-angle mono-style plug. The optional Syringe Finger Switch (# [988896](#)) has a 9-pin, male, “DB” connector and does not fit directly into the Digital Syringe Dispenser. Existing owners of Digital Syringe Dispensers are not able to use the Syringe Finger Switch.

Solution: A new adapter cable (# 1053227) that has a 9-pin, female connector to a mono-style plug is being added to the Syringe Finger Switch (# 988896) so the Finger Switch can now be used with the Digital Syringe Dispenser (#883976). Simply insert the 9-pin connector end into the adapter and plug into the mono jack on the rear of the Digital Dispenser. **This adapter cable is being made available (at no charge) to customers who have previously purchased Syringe Finger Switch (#988896).**

Requests for this adapter cable should be sent to Loctite's® Equipment Customer Services Department and the adapter cable will be sent from the Rocky Hill, CT, USA facility.

Note: Syringe Finger Switch (# 988896) can be used with:

- Precision Syringe Dispenser # [97006](#)
- Analog Syringe Dispenser # [98417](#)
- Digital Syringe Dispenser # [883976](#)
- Posi-Link™ Volumetric Syringe Dispensing System Controller # [98377](#)

